How to connect the ´ON AIR´ sign to your Airlab

Tip

Ring

+12V

LED Strip