

HOW TO EXCHANGE A BOARD INSIDE AN AIRMATE

Dear,

First you need to put the console on a soft surface on its knobs and remove the bottom plate/frame. This can be done by using a screw driver and unscrew 3 bolts on the top of the front panel below the faders and all the screws that are fixing the frame to the connector back panel. Three on the bottom, one left and one right. Now carefully remove the bottom panel. Now you see all the pcb's.

Step 1 is to remove the knobs of the boards you need to replace on the front side. After that undo the nuts from the boards and turn around the console again. Now click "off" the flatcables of the boards and take them out of the mixer.

Please handle with care, because the SMD boards are very sensitive for static electricity.

Now you can repeat the same handlings in reverse with the new pcb boards.

Good luck